

**ENGINE POWER LOSS – TAKE-OFF ROLL**

- 1. THROTTLE.....CLOSED
- 2. BRAKES.....AS REQ
- 3. FUEL SELECTOR.....OFF
- 4. MAGNETO/STARTER SWITCH.....OFF
- 5. MASTER.....OFF

**ENGINE POWER LOSS – AFTER TAKEOFF & IN FLIGHT**

(RESTART PROCEDURES)

- 1. AIRSPEED.....85 KIAS
- 2. FUEL SELECTOR.....SELECT OTHER TANK
- 3. FUEL PRESSURE.....VERIFY IN GREEN ARC
- 4. FUEL BOOST PUMP.....ON
- 5. THROTTLE.....FULL FORWARD
- 6. PROPELLER.....FULL FORWARD
- 7. MIXTURE.....FULL FORWARD
- 8. MAGNETO STARTER..... VERIFY ON BOTH

IF ENGINE DOES NOT RESTART AFTER INITIAL ATTEMPTS

- a. MIXTURE.....IDLE CUTOFF (initially)
- b. THEN ADVANCE SLOWLY TOWARD RICH UNTIL ENGINE STARTS

IF ENGINE DOES NOT RESTART

ESTABLISH BEST GLIDE SPEED AND PROCEED TO FORCED LANDING EMERGENCY

AFTER ENGINE RESTARTS

- a. THROTTLE.....ADJUST AS REQUIRED
- b. PROPELLER.....ADJUST AS REQUIRED
- c. MIXTURE-RE-LEAN AS POWER IS RESTORED
- d. LAND AS SOON AS PRACTICAL AND CORRECT MALFUNCTION PRIOR TO NEXT FLIGHT

**ENGINE FIRE IN FLIGHT**

- 1. FUEL SELECTOR VALVE.....OFF
- 2. THROTTLE..... CLOSED
- 3. MIXTURE..... IDLE CUTOFF
- 4. MAGNETO/STARTER SWITCH.....OFF
- 5. CABIN VENTS & HEATING CONTROLS..CLOSED
- 6. COWL FLAPS.....CLOSED
- 7. LANDING GEAR.....DOWN or UP depending on terrain
- 8. WING FLAPS.....EXTEND as necessary

If fire is not extinguished, attempt to increase airflow over the engine by increasing glide speed and open cowl flaps. Proceed with **FORCED LANDING EMERGENCY**

**ELECTRICAL FIRE IN FLIGHT**

(SMOKE IN CABIN)

- 1. MASTER SWITCH.....OFF  
*(STALL WARNING AND GEAR WARNING ARE NOT AVAILABLE WITH MASTER SWITCH OFF)*
- 2. ALTERNATOR FIELD SWITCH.....OFF
- 3. ALL ELECTRICAL SWITCHES.....OFF
- 4. CABIN VENTILATION.....OPEN
- 5. HEATING CONTROLS.....AS DESIRED
- 6. CIRCUIT BREAKERS...CHECK to identify faulty circuit if possible.

If electrical power is essential for the flight, attempt to identify and isolate faulty circuit

- a. MASTER SWITCH.....ON
- b. ALTERNATOR FIELD SWITCH.....ON
- c. SELECT **ESSENTIAL** SWITCHES..... \*ON

\*ONE AT A TIME, PERMIT A SHORT TIME TO ELAPSE BEFORE ACTIVATING AN ADDITIONAL CIRCUIT

- 7. LAND AS SOON AS POSSIBLE.

**ENGINE FIRE DURING START ON THE GROUND**

- 1. MAGNETO/STARTER SWITCH..CONTINUE cranking  
If engine starts:

- a. POWER..... 1500RPM for several minutes or until fire is extinguished

If engine does NOT start:

- a. MAGNETO/STARTER SWITCH.....CONTINUE CRANKING
- b. MIXTURE.....IDLE/CUTOFF
- c. THROTTLE.....FULL FORWARD
- d. FUEL SELECTOR VALVE.....OFF
- e. MAGNETO/STARTER SWITCH.....OFF
- f. MASTER SWITCH..... OFF
- g. EXTINGUISH..... WITH FIRE EXTINGUISHER

**HIGH OIL TEMPERATURE**

NOTE – PROLONGED HIGH OIL TEMPERATURE INDICATIONS WILL USUALLY BE ACCOMPANIED BY A DROP IN OIL PRESSURE. IF OIL PRESSURE REMAINS NORMAL, THEN A HIGH TEMPERATURE MAY BE CAUSED BY A FAULTY GAUGE OR TEMPERATURE PROBE.

- 1. COWL FLAPS.....OPEN
- 2. AIRSPEED.....INCREASE
- 3. POWER.....REDUCE

PREPARE FOR POSSIBLE ENGINE FAILURE IF TEMPERATURE CONTINUES HIGH.

**LOW OIL PRESSURE**

- 1. OIL TEMPERATURE AND PRESSURE....MONITOR
- 2. PRESSURE BELOW 25 PSI.....EXPECT ENGINE FAILURE

PROCEED TO **FORCED LANDING EMERGENCY**

**FORCED LANDING EMERGENCY**

POWER OFF – GEAR RETRACTED OR EXTENDED

1. ELT.....**ARM**
2. SEAT BELTS/SHOULDER HARNESSSES....**SECURE**
3. CABIN DOOR.....**UNLATCHED**
4. FUEL SELECTOR VALVE.....**OFF**
5. MIXTURE.....**IDLE/CUTOFF**
6. MAGNETO/STARTER.....**OFF**
7. WING FLAPS.....**FULL DOWN (33°)**
8. LANDING GEAR **DOWN or UP** (DEPENDING ON TERRAIN)
9. APPROACH SPEED.....**AS SLOW AS POSSIBLE**
10. MASTER SWITCH.....**OFF** (PRIOR TO LANDING)
11. LANDING.....**LEVEL, TAIL LOW ATTITUDE**

**ENGINE ROUGHNESS**

1. ENGINE INSTRUMENTS.....**CHECK**
2. FUEL SELECTOR.....**OTHER TANK**
3. MIXTURE.....**RE-ADJUST FOR SMOOTH OPERATIONS**
4. MAGNETO/STARTER....**SELECT R OR L OR BOTH**  
If roughness disappears on single magneto,  
monitor power and continue on selected magneto  
SEE POH for power loss and rough engine WARNINGS
5. THROTTLE.....**REDUCE**  
CHECK TO SEE IF A LESSER THROTTLE SETTING CAUSES  
ROUGHNESS TO DECREASE  
IF SEVERE ENGINE ROUGHNESS CANNOT BE ELIMINATED  
**LAND AS SOON AS PRACTICABLE.**

**PROPELLER OVERSPEED**

1. THROTTLE.....**RETARD**
2. OIL PRESSURE.....**CHECK**
3. PROPELLER.....**DECREASE**, set if any control  
available
4. AIRSPEED.....**REDUCE**
5. THROTTLE.....**BELOW 2700 RPM**

**ALTERNATOR OVERVOLTAGE**

Steady voltage warning light and alternator field circuit breaker tripped.

1. AVIONICS MASTER.....**OFF**
2. MASTER.....**OFF, THEN ON**
3. ALTERNATOR Field Circuit Breaker.....**RESET**

If circuit breaker will not reset, the following procedures are required:

**ONLY RESET ALTERNATOR FIELD CIRCUIT BREAKER ONCE****OPEN DOOR**

1. AIRSPEED .....**95 KIAS**
2. PILOT'S STORM WINDOW .....**OPEN**
3. AIRCRAFT .....**RIGHT SIDE-SLIP**
4. DOOR.....**PULL SHUT & LATCH**

**LOW FUEL FLOW**

1. MIXTURE.....**RICH**
2. FUEL SELECTOR..... **OPPOSITE** (fullest) **TANK**  
If condition persists, use Fuel Boost Pump as necessary and  
**LANDING SHOULD BE MADE AS SOON AS PRACTICAL.**

**LANDING GEAR FAILURE**

1. AIRSPEED.....**132 KIAS** or less
2. LANDING GEAR ACTUATOR CIRCUIT BREAKER  
**PULL**
3. GEAR SWITCH.....**DOWN**
4. MANUAL GEAR SWITCH EXTENSION MECHANISM  
**LATCH FORWARD/LEVER BACK**  
To engage manual extension mechanism
5. T-HANDLE.....**PULL** (7-20 times)  
and RETURN until gear is down and locked.  
GEAR DOWN light illuminated, STOP when  
resistance is felt.
6. VISUAL GEAR DOWN INDICATON....**CHECK ALIGNMENT**
7. **RETURN LEVER** to normal position and secure latch
8. **RESET LANDING GEAR ACTUATOR C/B**  
(Warning – do not operate landing gear electrically with  
manual extension system engaged)

**FAILURE OF LANDING GEAR TO RETRACT**

1. AIRSPEED.....**BELOW 107 KIAS**
2. GEAR SWITCH.....**UP**

- If gear fails to retract, gear horn – sounding, gear annunciator lights and gear by-pass light – **illuminated**
- a. GR SAFETY BY PASS SWITCH.....**DEPRESS**  
and hold until landing gear fully retracted
  - b. GEAR DOWN and GEAR UNSAFE lights.... **OFF**
  - c. GEAR RELAYS CIRCUIT BREAKER.....**PULL**  
If gear fails to retract
  - d. EMERGENCY GEAR EXTENSION LEVER  
**VERIFY LACHED** IN PROPER POSITION
  - e. GEAR RELAY CIRCUIT BREAKER.....**RESET**
  - f. WHEN READY TO EXTEND LANDING GEAR  
airspeed .....**below 132KIAS**  
gear relay circuit breaker.....**RESET**  
gear switch.....**DOWN**  
If gear will not extend electrically – refer to  
LANDING GEAR FAILURE PROCEDURE

**ALTERNATOR OUTPUT LOW**

Voltage warning light flashing, ammeter showing discharge.

1. NON-ESSENTIAL ELECTRICAL EQUIPMENT...**OFF**
2. LAND, WHEN PRACTICAL, TO CORRECT

**NOTE – INTENTIONAL SPINS PROHIBITED**