



# WINGS OF CAROLINA FLYING CLUB

## CESSNA 152 WALK-AROUND CHECK LIST



### COCKPIT CHECK

Mag Key ----- On Panel  
 Documentation ----- Check  
 POH (AFM), W & B, Ck List--- Ck  
 Charts ----- As Required  
 Hobbs -----Check  
 Flashlight ----- As Required  
 Control Lock -----Remove  
 Fire Ext----- Check  
 Master----- ON  
 Interior Lighting -----Night Check  
 Exterior Lighting -----Night Check  
 Fuel Qty----- Min Required  
 Flaps----- Down  
 Master----- OFF

### EXTERIOR CHECK

L Fuel Sump -----Drain & Check  
 L Gear Leg ----- Check  
 L Wheel Chock -----Remove  
 L Wheel ----- Check  
 L Tire ----- Inflation & Condition  
 L Brake----- Pads & Leakage  
 L Fuselage ----- Check  
 L Stab Condition ----- Check  
 L Elev Wt & Hinge----- Check  
 Elev Ctr Hinge & Cables-- Check  
 Rudder Cables ----- Check  
 Tail Tiedown -----Remove  
 Elev Trim Actuator----- Check

Rudder Hinges & Wgt-----Check  
 Beacon & Antennas -----Check  
 Elev Trim Hinge -----Check  
 R Elev Wt & Hinge -----Check  
 R Stab Condition -----Check  
 R Fuselage -----Check  
 R Fuel Sump ----- Drain & Check  
 R Gear Leg -----Check  
 R Wheel Chock ----- Remove  
 R Wheel -----Check  
 R Tire -----Inflation & Condition  
 R Brake----- Pads & Leakage  
 R Flap Inbd Rollers -----Check  
 R Flap Actuator-----Check  
 R Flap Otbd Rollers-----Check  
 R Aileron Inbd & Ctr Hinge---- Ck  
 R Aileron Actuator-----Check  
 R Aileron Wts & Otbd Hinge-- Ck  
 R Wing Tip & Light-----Check  
 R Wing Leading Edge-----Check  
 R Tiedown ----- Remove  
 R Fuel Tank --- Check Qty & Cap  
 Wing Top & Antennas-----Check  
 Fuel Gascolator-----Drain & Ck  
 Oil-----Check Quantity  
 Access Door--- Check for Abnrml  
 Cowl Fasteners -----Check  
 Alternator Belt-----Check  
 Cowl Int-----Ck for Obstructions  
 Propeller-----Check  
 Spinner -----Check  
 Landing Lights -----Check

Air Filter ----- Check  
 Exhaust Stack ----- Check  
 Nose Gear Strut----- Check  
 Nose Steering ----- Check  
 Nose Wheel & Axle----- Check  
 Nose Tire ----- Inflation & Cond  
 Cowl Fasteners----- Check  
 Static Port----- Check  
 L Fuel Tank----Check Qty & Cap  
 Pitot Tube----- Check  
 Stall Warning----- Check  
 L Tiedown----- Remove  
 Fuel Tank Vent ----- Check  
 L Wing Leading Edge----- Check  
 L Wing Tip & Light ----- Check  
 L Aileron Wts & Otbd Hinge ---Ck  
 L Aileron Actuator----- Check  
 L Aileron Inbd & Ctr Hinge ----Ck  
 L Flap Otbd Rollers----- Check  
 L Flap Actuator ----- Check  
 L Flap Inbd Rollers----- Check

### GENERAL OVERVIEW

Ice or Snow Adherence --- Check  
 Ramp Obstructions ----- Check  
 Ramp Condition ----- Check  
 Aircraft Overall View ----- Check