

WCFC CESSNA 172 SP WALK AROUND CHECKLIST

INTERIOR

Mag key -----on panel
Control lock----- remove
Documents -----
POH (AFM), W&B, checklist
Charts----- as required
Flashlight----- as required
Fire extinguisher----- charged
Elevator trim----- takeoff
Fuel selector ----- BOTH
Fuel shutoff valve ----- IN (ON)
Avionics master----- OFF

Master switch -----ON

Avionics master-----ON
Avionics fan----- check
Avionics master----- OFF
Fuel quantity ----- check
Low fuel annunciators-----off
Oil press. & L VAC R-----on
Interior lighting----- night check
Exterior lighting ----- check
Pitot heat ----- test
Alternate static----- OFF
Annunciator panel----- test
Flaps ----- down
Lights & electrics ----- OFF

Master switch ----- OFF

EXTERIOR

LEFT FUSELAGE & EMPENNAGE

Left stabilizer
L elevator wt & hinges
Elevator center hinge & attachment
Elevator cables
Rudder cables
Tail tiedown----- remove
Rudder hinges & weight
Beacon & antennas
Elevator trim hinge
Elevator trim actuator
R elevator wt & hinge
R stabilizer

RIGHT FUSELAGE & WING

R fuselage
ELT antenna
R gear leg
R wheel chock-----remove
R wheel
R tire----- inflation & condition
R brake----- pads & leakage
R flap inboard rollers
R flap actuator
R flap outboard rollers
R aileron hinges
R aileron actuator
R aileron wts & outb hinge
R wing tip, nav & strobe lights
R wing leading edge
R tiedown-----remove
R wing fuel drain valves (5) -----
-----drain & check
R fuel tank- check quantity & cap
Wing top & antennas

FORWARD

Oil ----- 6-8 quarts
Fuel strainer quick drain valve ---
-----drain & check
Fuel reservoir drain valve-----
-----drain & check
Fuel selector drain valve-----
-----drain & check
Cowl fasteners
Engine cooling air inlets
Alternator belt
Cowl interior
Propeller
Spinner
Air filter
Exhaust stack
Nose gear strut
Nose wheel steering
Shimmy dampener
Nose wheel & axle
Nose tire
Cowl fasteners
Auxiliary power door ----- closed
Static port

LEFT WING

L wing fuel drain valves (5) -----
----- drain & check
L fuel tank--check quantity & cap
Pitot tube
L fuel tank vent
Stall warning
L tiedown----- remove
Landing & taxi lights
L wing leading edge
L wing tip, nav & strobe lights
L aileron wts & hinges
L aileron actuator
L aileron hinges
L outbd flap rollers
L flap actuator
L flap inboard rollers
L gear leg
L wheel chock----- remove
L tire----- inflation & condition
L brake -----pads & leakage
Baggage door-----closed

OVERVIEW

Tiedowns
Chocks
Ice snow & frost
Ramp obstructions & conditions
Fuel