


Wings of Carolina Flying Club



MOONEY M20-J WALK AROUND CHECK LIST

COCKPIT CHECK

Mag Key - On Panel
Documentation - Check
POH (AFM), W&B, CK List - CK
Charts - As Required
Flashlight - As Required
Fire Ext - Check
Master - ON
Fuel Qty - Min Required
Stand By Vac - Check
Interior Lighting - Night Check
Exterior Lights - Night Check
Pitot Heat - For IFR, Check
Lights & Electrics - OFF
Master Switch - OFF
Sun Screens - Remove All

EXTERIOR CHECK

R Flap Hinge Fairings - Check
R Aileron Hinges - Check
R Aileron Actuator - Check
R Wing Tip & Lights - Check
R Wing Leading Edge - Check
R Fuel Tank - Check Qty & Cap
R Tiedown - Remove
R Fuel Tank Vent - Check
R Wheel Chock - Remove
R Gear Shock Discs - Check
R Gear Doors - Check
R Brake Line, Disc, Pads - CK
R Tire - Inflation & Condition
R Fuel Sump - Drain & Check

R Root Fairing - Check
Belly & Ventral Antennas - CK
R Cowl Flap & Stack - Check
R Cowl and Cowl Fasteners- CK
Windshield - Check Clean
Oil (6 min) - Check Quantity
Engine Compartment - Check
Alternator Belt - Check
Cowl Inlets - Check for Obstr
Air Filter - Check
Propeller - Check
Spinner - Check
Ram Air Port - Check
Landing Light/Cover - Check
Nose Gear Truss - Check
Nose Wheel & Tire - Check
Nose Gear Door: - Check
L Cowl Flap & Drains - Check
L Cowl Fasteners - Check
Pitot Drain - Check if Req
L Wing Root Fairing - Check
L Fuel Sump - Drain & Check
L Wheel Chock - Remove
L Gear Shock Discs - Check
L Gear Doors - Check
L Brake Line, Disc, Pads - CK
L Tire - Inflation & Condition
L Fuel Tank Vent - Check
L Tiedown - Remove
L Fuel Tank - Check Qty & Cap
Stall Warn - Check Microswitch
Pitot Tube - Check
L Wing Leading Edge - Check
L Wing Tip & Light - Check

L Aileron Hinges - Check
L Aileron Actuator - Check
L Flap Hinge Fairings - Check
E & E Panel - Check Secure
L Aft Fuselage - Check
Static Drain - Check if Req
Battery Vents - Check
L Static Port - Check
Empennage (Trim) Fairings -CK
Horiz Stab Movement - Check
L Elevator Hinges & Wt - Check
Tailcone & Elev Contr - Check
Tail Light/Strobe - Check
Tail Tiedown - Remove
Rudder Hinges & Wgt - Check
VOR Antennas - Check
R Elevator Hinges & Wt - Check
R Aft Fuselage - Check
R Static Port - Check
Dorsal Antennas - Check
Baggage Door - Secure & Test
Fuel Gascolator -Drain & Check

GENERAL OVERVIEW

Ice or Snow Adherence - Check
Ramp Obstructions - Check
Ramp Condition - Check
Aircraft Overall View- Check