

Mooney Hobbs and Tachometer Readings

Finding the Meters

Tach Time is displayed by the CGR-30P digital engine monitor. See below for instructions.

Hobbs time is either at the bottom-left of the breaker panel (68X), or on the center pedestal below the engine controls (60R).

Video Reference

<https://youtu.be/d3jyvOvEboY>



1. Use the "S" button to get to the page with Fuel Pressure and Oil Pressure.
2. Press and hold the center knob until a menu appears.
3. Turn the knob to select "Clock and Hour Meters" then press the knob once.
4. Read "Tach Hrs" at bottom-left.

Reporting Discrepancies

If you find that the starting Hobbs time in Flight Circle does not match the actual reading in the aircraft:

1. Notify a Club Administrator immediately to have the record corrected.
2. Proceed with your flight and ensure you record the correct *ending* times to facilitate the manual correction later.

Contact for Corrections: board@wingsofcarolina.org